babycakes™
chocolatier

Model # SC-1012 Instruction Manual

For more information, visit us online at www.thebabycakesshop.com

IMPORTANT SAFEGUARDS

When using electrical appliances especially when children are present, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

1. READ ALL INSTRUCTIONS.
2. Do not touch hot surfaces. Use any handles or knobs. Use pot holders when removing cover or handling hot containers.
3. To protect against electrical shock, do not place cord, plug or appliance in water or other liquid.
4. Close supervision is necessary when any appliance is used by or near children.
5. Unplug from outlet when not in use and before cleaning. Allow to cool before cleaning.
6. Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner. Return appliance to the nearest authorized service facility for examination, repair or adjustment.
7. The use of accessory attachments not recommended by the appliance manufacturer may cause injury.
8. Do not use outdoors.
9. Do not let cord hang over edge of table or counter or touch hot surfaces.
10. Do not place on or near a hot gas or electric burner, or in a heated oven.
11. Extreme caution must be used when moving an appliance containing hot food, water or other hot liquids.
12. Do not use appliance for other than intended use.
13. Lift and open cover carefully to avoid scalding, and allow water to drip into unit.
14. To disconnect, turn control to Off, then remove plug from wall outlet.
15. Containers are designed for use with this appliance only. Container should never be used on a rangetop. Do not set a hot container on a wet or cold surface. Do not use a cracked container.
16. FOR HOUSEHOLD USE ONLY.

SAVE THESE INSTRUCTIONS

OPERATING INSTRUCTIONS

PRODUCT MAY VARY SLIGHTLY FROM ILLUSTRATIONS

1. Plastic Lid
2. Removable Stoneware Insert
3. 2½ Cup Capacity

ACCESSORIES:

Spiral Spoon

Mesh Dipping Tool

This appliance is for HOUSEHOLD USE ONLY. It may be plugged into an AC electrical outlet (ordinary household current). Do not use any other electrical outlet.
DO NOT OPERATE APPLIANCE IF THE LINE CORD SHOWS ANY DAMAGE, OR IF APPLIANCE WORKS INTERMITTENTLY OR STOPS WORKING ENTIRELY.

A short power-supply cord (or detachable power-supply cord) is to be provided to reduce the risk resulting from becoming entangled in or tripping over a longer cord. Longer detachable power-supply cords or extension cords are available and may be used if care is exercised in their use. If a longer detachable power-supply cord or extension cord is used,

1. The marked electrical rating of the cord set or extension cord should be at least as great as the electrical rating of the appliance, and
2. The cord should be arranged so that it will not drape over the countertop or tabletop where it can be pulled on by children or tripped over unintentionally.

POLARIZED PLUG

This appliance has a polarized plug (one blade is wider than the other). To reduce the risk of electric shock, this plug is intended to fit into a polarized outlet only one way. If the plug does not fit fully into the outlet, reverse the plug and try again. If it still does not fit, contact a qualified electrician. Do not attempt to modify the plug in any way.

LINE CORD SAFETY TIPS

1. Never pull or yank on cord or the appliance.
2. To insert plug, grasp it firmly and guide it into outlet.
3. To disconnect appliance, grasp plug and remove it from outlet.
4. Before each use, inspect the line cord for cuts and/or abrasion marks. If any are found, this indicates that the appliance should be serviced and the line cord replaced.
5. Never wrap the cord tightly around the appliance, as this could place undo stress on the cord where it enters the appliance and cause it to fray and break.

During the first few minutes of initial use, you may notice smoke and/or a slight odor. This is normal and should quickly disappear. It will not recur after appliance has been used a few more times.

BEFORE USING
Solid surface countertops can be easily scratched, cracked, scorched, or damaged, especially when exposed to heat. To prevent damage, the following precautions should be observed when using this product:

- Always use a trivet under heat generating sources such as Slow Cookers, Toaster Ovens, Skillets, etc.
- Do not place hot pans, pots, ceramic or stoneware inserts, etc. directly on the countertop surface.
- Slow Cooker stoneware inserts have a rough bottom. To avoid scratching surfaces, always place the stoneware insert on a heat resistant placemat or trivet.

Carefully unpack the chocolatier and remove any labels or packaging materials. Wash stoneware insert and lid in warm, soapy water. Rinse well and dry thoroughly. Wipe interior and exterior surfaces of the base with a soft, moist cloth to remove dust particles collected during packing and handling. NEVER IMMERSE THE BASE, CORD OR PLUG IN WATER OR ANY OTHER LIQUID. Product should be operated before initial use. After cleaning, place insert inside the base. Pour ½ cup of water into the stoneware insert and cover with lid. Plug into electrical wall outlet and allow to operate approximately 20 minutes. After 20 minutes unplug. Allow unit to cool. Remove insert and discard water. Rinse the stoneware insert, dry thoroughly and place it into the base.

STONEWARE INSERT
Like any piece of cookware, the stoneware insert may crack or break if not properly handled. Failure to follow these instructions can cause breakage resulting in injury or property damage.

- Stoneware insert is breakable. Handle with care.
- ALWAYS USE POT HOLDERS WHEN HANDLING HOT STONEWARE INSERT.
- **DO NOT** place hot insert on counter. Use protective trivet.
- **DO NOT** strike utensils against rim to dislodge food.
- **DO NOT** use stoneware insert to pop corn, caramelize sugar, or make candy.
- **DO NOT** use abrasive cleaners, scouring pads, or any object that will scratch the stoneware insert.
- **DO NOT** use or repair any insert that is chipped, cracked, or broken.
- Bottom of product may be rough. To avoid scratching surfaces, place on place mat, tablecloth, or trivet.
- **DO NOT** use stoneware insert for reheating foods or for general food storage.
- **NEVER** heat the slow cooker base without the insert in place.

CARE: Use only wooden, nylon, or plastic utensils. Metal utensils can scratch. Insert can be washed by hand or in a dishwasher. Load carefully to avoid contact with, and bumping against, other items during cycle.
DO NOT allow stoneware insert to soak/stand in water for an extended period of time. If scouring is necessary, use only plastic or nylon cleaning pads with nonabrasive cleaners.

- When removing the insert from microwave, be sure to use pot holders or oven mitts.
- Always use pot holders or oven mitts when removing stoneware insert from chocolatier base. Do not set insert directly on counter top or table; use a trivet or hot pad.
- Unplug unit and allow to cool after use. Do not pour cold water into hot insert.

HOW TO USE

The chocolatier is intended to keep chocolate or candy toppings melted at the proper temperature for dipping baked foods, cake pops, candies or fruit while decorating. It can also be used to heat, hold and serve your favorite cheese, dips and appetizers at the ideal temperature.

1. Fill the chocolatier. The capacity is between 16 and 20 ounces.
2. Plug the power cord of the mini crock into the wall outlet.

3. Heat the contents until they are fully melted and hot, stirring occasionally. Depending upon volume of ingredients, this should take between 30 and 75 minutes.
4. Decorate, serve and enjoy. The contents of the chocolatier should remain warm for up to 4 hours. Keeping the lid in place will help to hold the contents at the desired consistency. **NOTE: This chocolatier should not be used to cook foods. It will not cook meat, so any ingredients should be pre-cooked prior to placing them in the ceramic insert.**

CHOCOLATE AND CANDY MELTS:

The removable stoneware insert makes it convenient to melt chocolates or candy melts and then keep them at the proper consistency for decorating using a single dish.

1. Place candy melts, chocolate, frosting or desired recipe in removable stoneware insert. **It is recommended to follow package directions for candy melts, but the following can be used as a general guide.**
2. Place stoneware insert in microwave and heat at 40% to 50% power for 1 minute.
3. Remove stoneware insert from microwave and stir contents.
4. Return insert to microwave and heat in 30 second intervals, stirring after every 30 seconds until desired consistency is reached.
5. Place stoneware insert into BABYCAKES chocolatier and plug into wall outlet. The BABYCAKES chocolatier should maintain the consistency while dipping and decorating.

USER MAINTENANCE INSTRUCTIONS

This appliance contains no user serviceable parts. Do not try to repair it yourself. Refer it to qualified service personnel if servicing is needed.

PRECAUTIONS:

- **Always unplug from wall outlet and allow to cool before cleaning.**
- Always handle ceramic insert carefully. Avoid hitting against faucet or hard surfaces.
- Do not touch sides of chocolatier while food is cooking. Use pot holders or oven mitts when removing the stoneware insert.

TO CLEAN:

This appliance should be cleaned after every use.
After unit has been allowed to cool, wash insert and lid in warm, soapy water. Rinse well and dry. If food sticks to the surface of the insert, fill the pot with warm, soapy water and allow it to soak for a short time before cleaning.
Wipe interior and exterior surfaces of the base with a soft, slightly damp cloth or sponge.
NEVER IMMERSE THE BASE IN WATER.
NEVER USE ABRASIVE CLEANSERS OR SCOURING PADS TO CLEAN THE INSERT OR BASE, AS THESE CAN DAMAGE THE SURFACES.

Dishwasher Cleaning

The recommended cleaning method for this product is by hand as described as above, but if proper care is taken, the stoneware insert and plastic lid may be cleaned in an automatic dishwasher. To prevent damage, position the stoneware insert in the rack so that it will not hit other items during cleaning. THE LID SHOULD BE PLACED ON THE TOP RACK ONLY.

TO STORE:

Be sure all parts are clean and dry before storing. Store appliance in its box or in a clean, dry place. Never store it while it is hot or wet. To store, place ceramic pot inside the base and the plastic lid over the pot. Never wrap cord tightly around the appliance; keep it loosely coiled.

GLAZES AND CANDY COATING RECIPES

Candy Melts

Candy melts are readily available at craft and hobby stores as well as stores specializing in cake decorating or candy making. Melt according to package directions.

Tip: If candy melts are too thick, add 1 to 2 tablespoons of shortening.

Almond Bark Coating

Add 1 to 2 tablespoons shortening to each 12 ounces of almond bark to make a dipping consistency. Melt according to package directions.

White Chocolate Glaze

Ingredients:

- 1 package (6 ounces) white chocolate
- 3 tablespoon heavy whipping cream
- 3 tablespoons butter, cut into thirds and softened
- ½ cup confectioners' sugar, sifted
- ½ teaspoon vanilla

Directions:

1. Combine white chocolate and cream in removable stoneware insert. Microwave on HIGH power (100%) for 1 minute. Stir. Add butter and microwave on HIGH power (100%) for 30 seconds. Stir. Microwave on HIGH power (100%) for an additional 10 to 15 seconds if necessary for white chocolate and butter to melt.
2. Blend in sugar and vanilla. Stir until smooth.
3. Dip cake pops or other food in warm frosting dip. Place insert into BABYCAKES chocolatier to keep a glaze consistency.

Makes about 1 cup of glaze

Frosting Dip

Ingredients:

- 1 container (16 ounces) Creamy Chocolate, Vanilla or Lemon Frosting *
- ½ cup semi-sweet chocolate or vanilla chips *

Directions:

1. Spoon frosting into removable stoneware insert. Microwave on HIGH power (100%) for 1 minute. Stir well. Blend in chips. Microwave on HIGH power (100%) for 1 minute.
2. Allow to stand 2 to 3 minutes. Stir. Microwave on HIGH power (100%) for an additional 10 to 15 seconds if necessary to melt chips. Stir until smooth.
3. Dip cake pops in warm frosting dip.
4. Place insert into BABYCAKES chocolatier and plug into wall outlet to keep a glaze consistency.

Makes about 1⅔ cups of frosting

**Tip: Choose complimentary flavors of frosting and chips. For example, blend semi-sweet chocolate chips into chocolate frosting or vanilla chips into vanilla or lemon frosting.*

Vanilla Glaze

Ingredients:

- ¼ cup melted butter
- 1¼ cups confectioners' sugar, sifted
- 1 teaspoon vanilla
- 2 to 2½ tablespoons hot water

Directions:

1. Combine melted butter with confectioners sugar, stirring until well blended.
2. Stir in vanilla.
3. Blend in 2 tablespoons hot water and stir until smooth.
4. Add a little of the remaining hot water, if needed, to make a thin glaze consistency.

Makes about ¾ cup of glaze

ONE YEAR LIMITED WARRANTY

SELECT BRANDS, INC. warrants, subject to the conditions stated below, that from the date of purchase, this product will be free from mechanical defects for a period of one (1) year. SELECT BRANDS, INC., at its option, will repair or replace this product found to be defective during the warranty period. Should this product become defective by reason of improper workmanship or material defect during the specified warranty period, Select Brands, Inc. will repair or replace the same effecting all necessary parts replacements for a period of one year from the date of purchase. Transportation charges on parts, or products in whole, submitted for repair or replacement, under this warranty, must be borne by the purchaser.

CONDITIONS: This warranty is valid for the original retail purchaser from the date of initial retail purchase and is not transferable. Keep the original sales receipt. Proof of purchase is required to obtain warranty service or replacement. Dealers, service centers, or retail stores do not have the right to alter, modify or in any way, change the terms and conditions of this warranty. Warranty registration is not necessary to obtain warranty on Select Brands, Inc. products. Save your proof of purchase receipt.

ABOUT YOUR PRODUCT WARRANTY: Most warranty repairs are handled routinely, but sometimes requests for warranty service may not be appropriate. For example, warranty service would NOT apply if the product damage occurred because of misuse, lack of routine maintenance, shipping, handling, warehousing or improper installation. Similarly, the warranty is void if the manufacturing date or the serial number on the product has been removed or the equipment has been altered or modified. During the warranty period, the authorized service dealer, at its option, will repair or replace any part that, upon examination, is found to be defective under normal use and service.

NORMAL WEAR: This warranty does not cover normal wear of parts or damage resulting from any of the following: Negligent use or misuse of the product; Improper voltage or current; Use contrary to the operation instructions; Deviation from instructions regarding storage and transportation; Repair or alteration by anyone other than SELECT BRANDS, INC. or an authorized service center. Further, the warranty does not cover Acts of God, such as fire, flood, hurricanes and tornadoes.

SELECT BRANDS, INC. shall not be liable for any incidental or consequential damages caused by the breach of any express or implied warranty. Except to the extent prohibited by applicable law, any implied warranty of merchantability or fitness for a particular purpose is limited in duration to the duration of the above warranty. Some states, provinces or jurisdictions do not allow the exclusion or limitation of incidental o consequential damages or limitations on how long an implied warranty lasts, so the above limitations or exclusion may not apply to you. This warranty gives you specific legal rights, and you may also have other rights that vary from state to state or province to province.

HOW TO OBTAIN WARRANTY SERVICE: You must contact SELECT BRANDS, INC. Customer Service at 1-913-663-4500. A Customer Service representative will attempt to resolve warranty issues over the phone. If telephone resolution is not possible, the Customer Service representative will require your assistance in performing routine diagnostic procedures. This warranty is effective for the time periods listed above and subject to the conditions provided for in this policy.

To view other **BABYCAKES** products, visit us online at www.thebabycakesshop.com

BABYCAKES is a registered trademark of Select Brands, Inc. 66219

Made in China

babycakes™

www.thebabycakesshop.com

Babycakes is a registered trademark of Select Brands, Inc. Lenexa, KS 66219 USA
Babycakes est une marque déposée de Select Brands, Inc. Lenexa, KS 66219 – États-Unis